

FIRING PIN SPRING

[Handgun Parts](#) > [Action Parts](#) > [Firing Pin Parts](#) > [Firing Pin Springs](#)

Firing Pin Spring 24N (silver) - fits all models (the end with the most coils goes toward the spring cups)



Attributes

- Name: [FIRING PIN SPRING](#)
- Manufacturer: [GLOCK](#)
- Product no.: 100002677
- Mfr. No.:
- Make: Glock
- Model: Universal Handguns
- Delivery weight: 0.005kg
- Shipping width: 88mm
- Shipping length: 126mm

Table of Contents

- Startpage
- Firing Pin Spring Safety Instructions
- About Us

Firing Pin Spring Safety Instructions

Introduction

Thank you for choosing the Firing Pin Spring 24N (silver), designed to fit all Glock models. This guide provides essential safety instructions to ensure the safe use and installation of your product. Please read this manual carefully before use.

General Safety Guidelines

- Always handle the firing pin spring with care to prevent injury.
- Ensure that the product is used only for its intended purpose.
- Keep the firing pin spring out of reach of children and vulnerable individuals.
- Regularly inspect the firing pin spring for any signs of wear or damage.
- Report any unsafe conditions or incidents involving the firing pin spring to the relevant authorities.
- Stay informed about recall updates through the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Before installation, ensure that the firearm is unloaded and pointed in a safe direction.
- Use protective eyewear when handling and installing the firing pin spring.
- Do not modify the firing pin spring or use it in a manner not specified by the manufacturer.
- Ensure that the spring is properly oriented during installation; the end with the most coils should face the spring cups.
- If you experience any difficulty during installation or usage, stop and consult a qualified professional.

Instructions for Installation and Usage

1. Preparation

- Ensure the firearm is unloaded and in a safe environment.
- Gather necessary tools for installation (if applicable).

2. Installation Steps

- Identify the correct orientation of the firing pin spring. The end with the most coils should go toward the spring cups.
- Carefully insert the firing pin spring into the designated area of the firearm, ensuring it is seated properly.
- Doublecheck the installation to confirm that the spring is correctly positioned.

3. Usage

- After installation, perform a function check to ensure the firearm operates correctly.
- Regularly inspect the firing pin spring during routine maintenance of the firearm.

Disposal Instructions

- Dispose of the firing pin spring in accordance with local regulations for metal waste.
- Do not dispose of the product in household waste.
- Contact your local waste management authority for proper disposal methods.

Contact Information for Further Support

For any safety inquiries or support related to the Firing Pin Spring, please reach out to your local authorized dealer or manufacturer's representative. They can provide guidance and assistance as needed.

Thank you for your attention to these safety guidelines. Your safety and the safe operation of your firearm are our top priorities.

About Us

Brownells Austria

Brownells - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

www.brownells.at