

FIRING PIN SAFETY & SPRING

[Handgun Parts](#) > [Action Parts](#) > [Firing Pin Parts](#) > [Firing Pin Locks](#)

FITS: Model 17, 9mm; Model 19, 9mm; Model 20, 10mm; Model 22, .40 S&W; Model 23, .40 S&W; Model 26, 9mm; Model 27, .40 S&W; Mod 29, 10mm; Mod 31, .357 SIG; Mod 32, .357 SIG; Mod 33, .357 SIG; Mod 34, 9mm; Mod 35, .40 S&W

Firing Pin Safety including Spring fits 9mm, .40, .357, 10mm



Attributes

- Name: [FIRING PIN SAFETY & SPRING](#)
- Manufacturer: [GLOCK](#)
- Product no.: 100002679
- Mfr. No.:
- Make: Glock
- Model: 17,19,20,22,23,26,27,29,31,32,33,34,35
- Delivery weight: 0.005kg
- Shipping width: 56mm
- Shipping length: 98mm

Item details

US export classification: 0A501.x

Table of Contents

- [Startpage](#)
- [Firing Pin Safety & Spring Safety Instructions](#)
- [About Us](#)

Firing Pin Safety & Spring Safety Instructions

Introduction

Thank you for choosing the Firing Pin Safety & Spring designed for Glock models 29, 20, 17, 19, 22, 23, 34, 35, 26, 27, 31, 32, 33. This product is essential for ensuring the safe operation of your firearm. Please read this safety instruction guide carefully to understand the proper use, installation, and disposal of the product.

General Safety Guidelines

- Ensure that the Firing Pin Safety & Spring is compatible with your specific Glock model before installation.
- Always handle firearms with care and follow all safety protocols.
- Store the product in a safe, dry place away from children and unauthorized users.
- Regularly check for any signs of wear or damage to the Firing Pin Safety & Spring. Replace if necessary.
- Report any unsafe products or accidents to the relevant authorities and check for recall updates on the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Always ensure the firearm is unloaded before attempting to install or replace the Firing Pin Safety & Spring.
- Use only original or manufacturer-approved parts to maintain safety and functionality.
- If you are unsure about the installation process, seek assistance from a qualified gunsmith.
- Do not modify the Firing Pin Safety & Spring or any other firearm components.
- Keep your workspace clear of distractions when working with firearms.

Instructions for Installation and Usage

1. Preparation

- Ensure the firearm is completely unloaded.
- Gather necessary tools, including a punch tool and screwdriver.

2. Installation Steps

- Remove the slide from the firearm according to the manufacturer's instructions.
- Locate the Firing Pin Safety mechanism in the slide assembly.
- Carefully remove the old Firing Pin Safety & Spring, if present.
- Install the new Firing Pin Safety & Spring by aligning it properly and securing it in place.
- Reassemble the slide and ensure all components are fitted correctly.

3. Usage Guidelines

- After installation, conduct a function check to ensure the safety mechanism operates correctly.
- Regularly inspect the Firing Pin Safety & Spring during routine maintenance of your firearm.
- Follow all operational guidelines provided by the firearm manufacturer.

Disposal Instructions

- Dispose of any damaged or old Firing Pin Safety & Spring in accordance with local regulations.
- Do not dispose of the product in regular household waste. Check with local authorities for proper disposal methods.
- Consider recycling options where available.

Contact Information for Further Support

For any inquiries regarding the Firing Pin Safety & Spring, please contact the manufacturer or your local dealer. They can provide additional support and guidance on safety practices and product maintenance.

By following these safety instructions, you can ensure the safe and effective use of your Firing Pin Safety & Spring. Thank you for prioritizing safety in your firearm practices.

About Us

Brownells Austria

Brownells - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

www.brownells.at