

# TRIGGER SPRING FOR GLOCK PISTOLS

[Handgun Parts](#) > [Trigger Group Parts](#) > [Trigger Parts](#) > [Trigger Springs](#)

Trigger Spring - Coil - fits all models (current style spring has a battleship-gray coating)



## Attributes

- Name: [TRIGGER SPRING FOR GLOCK PISTOLS](#)
- Manufacturer: [GLOCK](#)
- Product no.: 100002691
- Mfr. No.:
- Make: Glock
- Model: Universal Handguns
- Delivery weight: 0.005kg
- Shipping width: 57mm
- Shipping length: 89mm

# Table of Contents

- Startpage
- TRIGGER SPRING FOR GLOCK PISTOLS Safety Instruction Guide
- About Us

# TRIGGER SPRING FOR GLOCK PISTOLS Safety Instruction Guide

## Introduction

Thank you for choosing the TRIGGER SPRING for Glock pistols. This guide provides essential safety instructions to ensure the proper use and installation of the product. It is crucial to adhere to these guidelines to maintain safety and functionality.

## General Safety Guidelines

- Ensure that the product is suitable for your specific model of Glock pistol.
- Always handle firearms with care and follow all local laws and regulations regarding firearm safety.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the trigger spring for signs of wear or damage before use.
- In case of any malfunction or unusual behavior of your firearm, cease use immediately and consult a qualified gunsmith.

## Specific Safety Precautions for Use

- Only use the TRIGGER SPRING in Glock pistols as specified.
- Do not attempt to modify the trigger spring or any other components of your firearm.
- Always ensure that the firearm is unloaded before performing any maintenance or installation.
- Wear appropriate safety gear, such as safety glasses, when handling firearms.
- Be aware of your surroundings and ensure that you are in a safe location when using your firearm.

## Instructions for Installation and Usage

### 1. Preparation:

- Ensure that the firearm is unloaded and pointed in a safe direction.
- Gather necessary tools for installation (e.g., screwdriver).

### 2. Installation:

- Remove the slide and frame of the Glock pistol according to the manufacturer's instructions.
- Locate the trigger assembly and carefully remove the old trigger spring.
- Install the new TRIGGER SPRING by following the reverse order of removal.
- Ensure that the spring is securely in place and properly aligned.

### 3. Testing:

- After installation, reassemble the firearm and perform a function check to ensure proper operation.
- Test the trigger mechanism in a safe environment before using the firearm in a live setting.

### 4. Usage:

- Follow all standard safety protocols when operating your Glock pistol.
- Regularly check the condition of the trigger spring and replace it if any issues are detected.

## Disposal Instructions

- Dispose of the old trigger spring and any packaging materials in accordance with local regulations.

- Do not dispose of the product in regular household waste; check for recycling options in your area.

## **Contact Information for Further Support**

For any safety inquiries or further assistance regarding the TRIGGER SPRING, please consult your local Glock dealer or authorized service center. You may also refer to the EU Safety Gate platform for updates on product safety and recalls.

By following these guidelines, you can help ensure a safe and effective experience with your TRIGGER SPRING for Glock pistols. Thank you for your attention to safety.

# About Us

## Brownells Austria

**Brownells - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories**

[www.brownells.at](http://www.brownells.at)