

TRIGGER HOUSING PIN FOR GLOCK® - TRIGGER HOUSING PIN FOR GLOCK 17, 19, 20, 21, 22, 23 BLACK

[Handgun Parts](#) > [Trigger Group Parts](#) > [Trigger Parts](#) > [Trigger Pins](#)

PART# 1774 /BROWNELLS SKU 100002707: Trigger Housing Pin - Polymer - fits

Glock® Gen4's without the MBS (BOTH) and the Gen3 G36 and G30S PART#

427 /BROWNELLS SKU 100002695: Trigger Housing Pin - Polymer - fits all

Glock® models except G36.



Attributes

- Name: [TRIGGER HOUSING PIN FOR GLOCK 17, 19, 20, 21, 22, 23 BLACK](#)
- Manufacturer: [GLOCK](#)
- Product no.: 100002695
- Mfr. No.:
- Make: Glock
- Model: 17,19,20,21,22,23,26,27,29,30,31,32,33,34,35,37,38
- Delivery weight: 0.045kg
- Shipping height: 3mm
- Shipping width: 83mm
- Shipping length: 146mm

Table of Contents

- Startpage
- Safety Instruction Guide for TRIGGER HOUSING PIN FOR GLOCK®
- About Us

Safety Instruction Guide for TRIGGER HOUSING PIN FOR GLOCK®

Introduction

Thank you for choosing the TRIGGER HOUSING PIN FOR GLOCK®. This product is designed for use with various Glock models, ensuring reliable performance and safety. Please read this safety instruction guide carefully to ensure safe usage and compliance with the EU General Product Safety Regulation (GPSR).

General Safety Guidelines

- Ensure that all users are familiar with the operation and handling of Glock firearms.
- Always handle firearms with care and in accordance with local laws and regulations.
- Store the TRIGGER HOUSING PIN in a cool, dry place away from direct sunlight.
- Keep the product out of reach of children and unauthorized persons.
- Regularly check for signs of wear or damage to the product before use.
- Report any unsafe products or accidents to the appropriate authorities.

Specific Safety Precautions for Use

- Only use the TRIGGER HOUSING PIN with compatible Glock models as specified in the product description.
- Ensure that the firearm is unloaded before attempting to install or replace the trigger housing pin.
- Avoid using excessive force during installation to prevent damage to the firearm or the pin.
- Do not modify the trigger housing pin or use it in a manner not intended by the manufacturer.
- If you experience difficulty during installation, consult a qualified gunsmith.

Instructions for Installation and Usage

1. Preparation:

- Ensure the firearm is completely unloaded.
- Gather necessary tools, if any, for installation.

2. Installation:

- Locate the trigger housing on your Glock model.
- Remove the existing trigger housing pin if applicable.
- Align the new TRIGGER HOUSING PIN with the trigger housing.
- Gently insert the pin until it is securely in place. Ensure it is flush with the housing.

3. PostInstallation Check:

- Verify that the pin is correctly installed and does not protrude excessively.
- Perform a function check of the firearm to ensure proper operation.

4. Usage:

- Use your Glock in accordance with the manufacturer's guidelines and safety practices.
- Regularly inspect the trigger housing pin during routine maintenance.

Disposal Instructions

- Dispose of the TRIGGER HOUSING PIN in accordance with local regulations regarding plastic waste.

- Do not dispose of the product in regular household waste. Instead, use designated recycling facilities if available.

Contact Information for Further Support

For any inquiries regarding the TRIGGER HOUSING PIN, please refer to the product packaging or visit the manufacturer's website for further assistance.

By following these safety instructions, you can ensure a safer experience while using the TRIGGER HOUSING PIN FOR GLOCK®. Thank you for prioritizing safety and compliance with EU regulations.

About Us

Brownells Austria

Brownells - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

www.brownells.at