

EXTRACTOR DEPRESSOR PLUNGER SPRING FOR GLOCK® GEN 3 - SHADOW SYSTEMS EXTRACTOR DEPRESSOR PLUNGER SPRING FOR GLOCK GEN 3

[Handgun Parts](#) > [Action Parts](#) > [Extractor Parts](#) > [Extractor Springs](#)

The Extractor Depressor Plunger Spring by Shadow Gunworks has been designed to replace the original factory spring in your 9mm Glock Gen 3. Made of 302 Stainless Steel Fits Glock Gen 3, models 17, 19, 22, 23, 26, 27, 34, 35



Attributes

- Name: [SHADOW SYSTEMS EXTRACTOR DEPRESSOR PLUNGER SPRING FOR GLOCK GEN 3](#)
- Manufacturer: [SHADOW SYSTEMS](#)
- Product no.: 100024246
- Mfr. No.: SG9C0113
- Model: 26,27,17,22,23,35,34,19
- Weapon type: Glock
- Delivery weight: 0.045kg
- Shipping height: 25mm
- Shipping width: 25mm
- Shipping length: 25mm
- UPC: 853687007141

Item details

Made in USA

Table of Contents

- Startpage
- Extractor Depressor Plunger Spring Safety Instructions
- About Us

Extractor Depressor Plunger Spring Safety Instructions

Introduction

Thank you for choosing the Extractor Depressor Plunger Spring for Glock® Gen 3 by Shadow Gunworks. This product is designed to enhance the performance of your Glock firearm. To ensure safe and effective use, please read and follow these safety instructions carefully.

General Safety Guidelines

- Ensure the product is compatible with your Glock model. This spring is designed for Glock Gen 3 models including 17, 19, 22, 23, 26, 27, 34, and 35.
- Always handle firearms safely and responsibly.
- Store the product in a safe place, out of reach of children and unauthorized users.
- Regularly inspect the spring for signs of wear or damage before use.
- Report any unsafe products or accidents to the relevant authorities.
- Check for recall updates on the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Do not use the Extractor Depressor Plunger Spring if it is damaged or worn.
- Always wear appropriate safety gear, such as eye protection, when handling firearms.
- Ensure the firearm is unloaded before installing or replacing the spring.
- Follow all manufacturer guidelines and local laws regarding firearm modifications.
- Keep the work area clean and free of distractions during installation.

Instructions for Installation and Usage

1. Preparation

- Ensure your firearm is unloaded and pointed in a safe direction.
- Gather necessary tools for installation, including a punch tool and a hammer.

2. Removal of the Old Spring

- Disassemble your Glock according to the manufacturer's instructions.
- Locate the extractor depressor plunger spring.
- Use the punch tool to carefully remove the old spring from its housing.

3. Installation of the New Spring

- Take the new Extractor Depressor Plunger Spring and ensure it is free from any debris.
- Insert the new spring into the housing, ensuring it is seated properly.
- Reassemble your Glock following the manufacturer's instructions.

4. Final Check

- Once reassembled, perform a function check to ensure the firearm operates correctly.
- Store the firearm safely when not in use.

Disposal Instructions

- Dispose of the old Extractor Depressor Plunger Spring in accordance with local regulations.
- Do not dispose of the spring in regular household waste.
- Consider recycling options where available.

Contact Information for Further Support

For any inquiries or additional support regarding the Extractor Depressor Plunger Spring, please reach out to the manufacturer or consult your local firearm safety authority.

By following these instructions and safety guidelines, you can ensure the safe and effective use of the Extractor Depressor Plunger Spring for your Glock Gen 3. Thank you for prioritizing safety and responsibility in your firearm practices.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk