

AR-15 A2 REAR SIGHT APERATURE - LUTH-AR AR-15 A2 REAR SIGHT APERATURE

[Rifle Parts](#) > [Sights](#) > [Rear Sights](#)

Luth-AR factory replacement A2 Rear Sight Aperature. Fits standard AR-15 A2 rifles.



Attributes

- Name: [LUTH-AR AR-15 A2 REAR SIGHT APERATURE](#)
- Manufacturer: [LUTH-AR](#)
- Product no.: 100028065
- Mfr. No.:
- Colour: Black
- Sight Color: Black
- Style: Factory Replacement
- Weapon type: AR-15
- Delivery weight: 0.045kg
- Shipping height: 25mm
- Shipping width: 25mm
- Shipping length: 25mm
- UPC: 859819007928

Item details

Made in USA

Table of Contents

- Startpage
- Safety Instruction Guide for AR15 A2 Rear Sight Aperture
- About Us

Safety Instruction Guide for AR15 A2 Rear Sight Aperture

Introduction

Thank you for choosing the LuthAR AR15 A2 Rear Sight Aperture. This guide provides essential safety information and instructions to ensure the safe use and installation of your product. Please read this document carefully before using the product.

General Safety Guidelines

- Ensure that the product is used in accordance with the manufacturer's instructions.
- Regularly inspect the sight for any signs of wear or damage. Do not use if damaged.
- Keep the product out of reach of children and vulnerable individuals.
- Report any unsafe conditions or incidents related to the product to the appropriate authorities.
- Stay informed about any product recalls or safety alerts via the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Always handle firearms with care and ensure they are unloaded before installing or adjusting any sights.
- Use only compatible AR15 A2 rifles with this sight to avoid malfunction or injury.
- Avoid exposing the sight to extreme temperatures or harsh environmental conditions which may affect its performance.
- Do not modify or alter the sight in any way as this may compromise safety and functionality.
- When adjusting the sight, ensure your firearm is pointed in a safe direction at all times.

Instructions for Installation and Usage

1. Installation:

- Ensure the AR15 A2 rifle is unloaded and pointed in a safe direction.
- Remove the existing rear sight if applicable, following the manufacturer's instructions.
- Align the LuthAR A2 Rear Sight Aperture with the mounting points on the rifle.
- Secure the sight in place using the appropriate screws or mounting hardware.
- Doublecheck that the sight is firmly attached and does not move when pulled.

2. Usage:

- Familiarize yourself with the sight's features and adjustments before use.
- When aiming, ensure proper eye relief and alignment with the front sight for accurate targeting.
- Make adjustments to the sight only when the firearm is in a safe condition.
- Regularly clean the sight to maintain visibility and performance.

Disposal Instructions

- Dispose of the product in accordance with local waste management regulations.
- Do not throw the product in regular household waste.
- Check for any recycling programs that may accept firearm accessories or materials.

Contact Information for Further Support

For any questions or concerns regarding the LuthAR AR15 A2 Rear Sight Aperture, please refer to the

manufacturer's website or customer service for assistance. Ensure you have the product information ready for reference.

By following these guidelines, you can ensure safe and effective use of your LuthAR AR15 A2 Rear Sight Aperture. Thank you for prioritizing safety.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk