

# SLIDE KIT FOR GLOCK® 17 - STRIKE INDUSTRIES SLIDE KIT FOR GLOCK®

[Home](#)

The Strike Industries Slide Completion Kit For GLOCK® GEN3 G17 features Made in the USA components you need to complete your slide minus a barrel and sights. Manufactured to the exact same specifications and tolerances using the same or better materials as original GLOCK® parts. This kit includes: Recoil Spring Assembly, Firing Pin & Spring, Firing Pin Spacer Sleeve, Firing Pin Spring Cups, Firing Pin Channel Liner, Extractor Depressor Plunger & Spring, Spring Loaded Bearing w/ Load Chamber Indicator (LCI), Firing Pin Safety & Spring, Extractor w/ LCI and Slide Cover Plate. Complete your build today with the Strike Industries Completion Kit For GLOCK® GEN3 G17. Components to complete your slide minus barrel and sights Manufactured to the exact same specifications and tolerances using the same or better materials as original GLOCK® parts Firing Pin: MIM 17-4 PH and hardened to H900 condition w/ Black Nitride finish Extractor w/ Loaded Chamber Indicator: MIM 17-4 PH and hardened to H900 condition Firing Pin Safety: 4140 steel w/ 42-46 Rc hardness Extractor Depressor Plunger: 4140 steel w/ 42-46Rc hardness Made in the USA



## Attributes

- Name: [STRIKE INDUSTRIES SLIDE KIT FOR GLOCK®](#)
- Manufacturer: [STRIKE INDUSTRIES](#)
- Product no.: 100043589
- Mfr. No.: SI-G-SLIDEKIT-17
- Model: 17
- Weapon type: Glock
- Delivery weight: 0.054kg
- Shipping height: 13mm
- Shipping width: 76mm
- Shipping length: 165mm
- UPC: 793811763959

## Item details

US export classification: 0A501.x

# Table of Contents

- Startpage
- Safety Instruction Guide for the Strike Industries Slide Kit for GLOCK® 17
- About Us

# Safety Instruction Guide for the Strike Industries Slide Kit for GLOCK® 17

## Introduction

Thank you for choosing the Strike Industries Slide Completion Kit for GLOCK® GEN3 G17. This guide provides essential safety instructions to ensure the proper use and handling of your product. Please read this document carefully before installation and usage.

## General Safety Guidelines

- Always handle your firearm and its components with care and respect.
- Ensure that the product is used only for its intended purpose.
- Keep the product out of reach of children and unauthorized users.
- Regularly inspect all components for signs of wear or damage before use.
- Adhere to all local laws and regulations regarding firearm usage and modifications.
- In case of any uncertainties regarding safety or use, consult a qualified gunsmith or firearms expert.

## Specific Safety Precautions for Use

- **Hazard Identification:** Improper installation or use of the slide kit may lead to malfunctions or accidents.
- **Avoiding Hazards:**
  - Always ensure the firearm is unloaded before installation or maintenance.
  - Do not modify the components beyond the manufacturer's specifications.
  - Use only compatible parts and accessories with your GLOCK® 17.
  - Wear safety glasses when handling or installing components to protect your eyes from debris.
  - Use appropriate tools to prevent injury during installation.
- **Age Specific Warning:** This product is intended for adult use only. Keep it away from children and individuals who are not trained in firearm safety.

## Instructions for Installation and Usage

### 1. Preparation:

- Gather all necessary tools and components from the kit.
- Ensure your workspace is clean and welllit.

### 2. Installation Steps:

- Confirm that your GLOCK® 17 is completely unloaded.
- Remove the slide from the frame according to the manufacturer's instructions.
- Follow the steps below to install each component:
  - **Recoil Spring Assembly:** Insert into the slide, ensuring it is seated properly.
  - **Firing Pin & Spring:** Place the firing pin in the designated channel and install the spring.
  - **Firing Pin Spacer Sleeve:** Position the sleeve on the firing pin.
  - **Firing Pin Spring Cups:** Insert the cups into their respective locations.
  - **Firing Pin Channel Liner:** Install the liner in the channel to reduce friction.
  - **Extractor Depressor Plunger & Spring:** Insert the plunger and spring into the extractor.

- **Spring Loaded Bearing w/ Load Chamber Indicator (LCI):** Install the bearing ensuring it moves freely.
- **Firing Pin Safety & Spring:** Place the safety in the channel and secure with the spring.
- **Extractor w/ LCI:** Attach the extractor to the slide.
- **Slide Cover Plate:** Finally, secure the cover plate to complete the assembly.

### 3. Final Checks:

- Ensure all components are securely installed and function smoothly.
- Reattach the slide to the frame and perform a function check to ensure proper operation.

## Disposal Instructions

- Dispose of any unused components or packaging materials in accordance with local regulations.
- Do not dispose of the product in regular household waste. Check for local recycling programs or hazardous waste disposal sites.

## Contact Information for Further Support

For safety inquiries or additional support regarding the Strike Industries Slide Completion Kit for GLOCK® GEN3 G17, please refer to the manufacturer's contact information available on their official website or product packaging.

By following these safety instructions, you can ensure a safe and effective use of your Strike Industries Slide Completion Kit for GLOCK® 17. Always prioritize safety and compliance with relevant laws and regulations. Thank you for your attention to these important guidelines.

# About Us

## Brownells UK

### **Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories**

Unit 1, Laughing Dog Industrial Estate  
London Road  
Rugby  
Warwickshire  
CV23 9LP

[www.brownells.co.uk](http://www.brownells.co.uk)