

Ammo Box 50rd Flip-Top 223 204 Ruger 6x47 Clear/Smoke - CHADWICK & TREFETHEN AMMO BOX 50RD FLIP-TOP 223 204 RUGER 6X47 CLEAR/SMOKE

[Shooting Accessories](#) > [Ammunition Storage](#) > [Ammo Boxes](#)

Ammo Box 50rd Flip-Top 223 204 Ruger 6x47 Clear/Smoke



Attributes

- Name: [CHADWICK & TREFETHEN AMMO BOX 50RD FLIP-TOP 223 204 RUGER 6X47 CLEAR/SMOKE](#)
- Manufacturer: [CHADWICK & TREFETHEN](#)
- Product no.: 250056822
- Mfr. No.: RS-50-41
- Delivery weight: 0.113kg
- Shipping height: 71mm
- Shipping width: 76mm
- Shipping length: 127mm
- UPC: 026057217826

Item details

Made in USA

Table of Contents

- Startpage
- Safety Instruction Guide for Ammo Box 50rd FlipTop 223 204 Ruger 6x47 Clear/Smoke
- About Us

Safety Instruction Guide for Ammo Box 50rd FlipTop 223 204 Ruger 6x47 Clear/Smoke

Introduction

Thank you for choosing the Ammo Box 50rd FlipTop 223 204 Ruger 6x47 Clear/Smoke by Chadwick & Trefethen. This guide provides important safety instructions and guidelines to ensure the safe use and handling of this product in compliance with the EU General Product Safety Regulation (GPSR).

General Safety Guidelines

- Ensure that the product is used only for its intended purpose: storing and organizing ammunition.
- Always keep the ammo box out of reach of children and unauthorized individuals.
- Regularly inspect the ammo box for any signs of damage or wear. Do not use if damaged.
- Follow all local laws and regulations regarding the storage and transportation of ammunition.
- In case of any safety concerns, report them to the appropriate authorities.

Specific Safety Precautions for Use

- Use the ammo box in a wellventilated area to avoid any potential buildup of harmful substances.
- Do not expose the ammo box to extreme temperatures or direct sunlight for prolonged periods.
- Avoid placing heavy objects on top of the ammo box to prevent deformation or damage.
- Ensure that the fliptop lid closes securely to prevent accidental opening.
- Do not overload the ammo box beyond its intended capacity of 50 rounds.

Instructions for Installation and Usage

1. Unpacking the Product

- Carefully remove the ammo box from its packaging.
- Inspect the box for any visible damage or defects.

2. Storing Ammunition

- Open the fliptop lid gently.
- Place the ammunition inside the box, ensuring it is organized and does not exceed the maximum capacity.
- Close the lid securely after use.

3. Transportation

- When transporting the ammo box, ensure it is secured to prevent movement.
- Avoid placing the ammo box in areas where it may be exposed to moisture or extreme temperatures.

4. Cleaning and Maintenance

- Regularly clean the exterior of the ammo box with a soft, damp cloth.
- Do not use harsh chemicals or abrasive materials that may damage the surface.

Disposal Instructions

- Dispose of the ammo box in accordance with local regulations regarding plastic waste.

- If the ammo box is damaged or no longer usable, ensure it is disposed of in a manner that prevents environmental harm.
- Do not burn the ammo box as it may release harmful substances.

Contact Information for Further Support

For any safety inquiries or concerns regarding the Ammo Box 50rd FlipTop 223 204 Ruger 6x47 Clear/Smoke, please refer to the contact information provided by the manufacturer.

Thank you for prioritizing safety and responsible use of your Ammo Box.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk