

RUGER® 10/22® MOE® X-22 RIFLE STOCK - RUGER 10/22 MOE HUNTER X-22 STOCK - GRAY

The MOE® X-22 Stock is the ideal rimfire stock for those looking for a lightweight, budget-friendly upgrade for their Ruger® 10/22®. Featuring M-LOK slots at the 6 o'clock position, as well as Magpul's own exclusive TSP texture on the pistol grip, the overall weight of the stock tips the scales at slightly more than a pound (19 oz.). The stock sports integral sling loops on the toe and fore end for use with locking sling swivels, and with the ergonomic nylon butt-pad, the stock has a length-of-pull measurement of 13.5". In short, the MOE X-22 Stock is built for lean efficiency. The MOE X-22 is available with two diameter barrel trays to support both factory pencil and bull-barrel profiles to provide shooters with options for various configurations. Lightweight at just over a pound at 19 oz. Ergonomic, non-slip, polymer butt-ad with angled toe TSP texture 2 M-LOK® slots at 6 o'clock Integral loops compatible with Uncle Mike's® sling swivels Interchangeable barrel trays for factory pencil and bull-barrel profiles Interchangeable barrel trays accept all factory barrels as well as aftermarket up to 0.920" diameter (12.5" minimum length) ensuring proper fit with pencil profile as well as heavy bull barrels Compatible with semi-auto and straight pull Ruger 10/22 style receivers. Same as Hunter® X-22 for receiver fitments. Factory pencil and bull-barrel profiles. Platform Ruger® 10/22 Compatibility Drop-in design compatible with factory Ruger 10/22 .22 LR receivers Butt-Pad Dimensions 1.5 x 4.5 in. Length 28.6 in. Length of Pull 13.5 in. Weight 18.9 oz.



Attributes

- Name: RUGER 10/22 MOE HUNTER X-22 STOCK - GRAY
- Manufacturer: MAGPUL
- Product no.: 430106907
- Mfr. No.: MAG1428-GRY
- Action Type: Rimfire
- Color: Gray
- Make: Ruger
- Material: Polymer
- Model: 10/22
- Style: Fixed
- Weight: 1.181 lbs
- Delivery weight: 1.202kg
- Shipping height: 83mm
- Shipping width: 171mm
- Shipping length: 819mm
- UPC: 840815147596

Item details

Made in USA

US export classification: 0A501.y.1

Table of Contents

- [Startpage](#)
- [English: RUGER® 10/22® MOE® X22 RIFLE STOCK Safety Instruction Guide](#)
- [Suomi: RUGER® 10/22® MOE® X22 RIFLE STOCK KÄYTTÖOHJEET](#)

RUGER® 10/22® MOE® X22 RIFLE STOCK Safety Instruction Guide

Introduction

Thank you for choosing the RUGER® 10/22® MOE® X22 Rifle Stock. This guide provides important safety information and instructions to ensure the safe use and maintenance of your product in compliance with the EU General Product Safety Regulation (GPSR). Please read this guide carefully before using the product.

General Safety Guidelines

- Ensure that the product is used only for its intended purpose as a stock for the Ruger® 10/22® rifle.
- Regularly inspect the rifle stock for any signs of damage or wear. Do not use the stock if it is damaged.
- Keep the stock and rifle out of reach of children and unauthorized users.
- Always follow local laws and regulations regarding the use of firearms and firearm accessories.
- Report any unsafe products or accidents to the appropriate authorities.
- Check for recall updates on the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Always ensure that the firearm is unloaded before attaching or detaching the stock.
- Avoid using the stock in adverse weather conditions that may affect its performance.
- Do not modify the stock in any way, as this may compromise its safety and functionality.
- Use only compatible accessories and components as specified in the product description.
- Ensure that the stock is properly secured to the receiver to prevent accidental detachment during use.
- Be aware of your surroundings and ensure a safe shooting environment at all times.

Instructions for Installation and Usage

Installation Instructions

1. **Preparation:** Ensure the firearm is completely unloaded and pointed in a safe direction.
2. **Remove the Existing Stock:** Follow the manufacturer's instructions to detach the existing stock from the Ruger® 10/22® receiver.
3. **Attach the MOE® X22 Stock:**
 - Align the stock with the receiver.
 - Secure the stock using the provided screws and tools, ensuring a tight fit.
 - Check that the stock is firmly attached and does not wobble.
4. **Adjust the Length of Pull:** The stock features an ergonomic design. Ensure the length of pull is comfortable for your shooting position.

Usage Instructions

- Familiarize yourself with the stock's features, including the MLOK slots and sling loops.
- When using the stock, ensure that your grip is firm and that you maintain control of the firearm at all times.
- Utilize the integral sling loops for secure carrying of the firearm when not in use.

Disposal Instructions

- Dispose of the product in accordance with local regulations regarding plastic and polymer materials.
- Do not incinerate or dispose of the stock in a manner that may harm the environment.
- If the stock is damaged beyond repair, consider recycling the material if possible.

Contact Information for Further Support

For any inquiries regarding the safety and use of the RUGER® 10/22® MOE® X22 Rifle Stock, please refer to the manufacturer's website or contact your local retailer for assistance.

Thank you for your attention to these safety guidelines. Your safety is our priority. Enjoy your shooting experience with the RUGER® 10/22® MOE® X22 Rifle Stock.

RUGER® 10/22® MOE® X22 RIFLE STOCK

KÄYTTÖOHJEET

Johdanto

Tervetuloa RUGER® 10/22® MOE® X22 RIFLE STOCK tuotteen käyttöohjeisiin. Tämä opas on suunniteltu auttamaan sinua käyttämään tuotetta turvallisesti ja tehokkaasti. Lue ohjeet huolellisesti ennen tuotteen käyttöä ja asennusta.

Yleiset turvallisuusohjeet

- Varmista, että tuote on tarkoitettu vain aikuisille käyttäjille.
- Säilytä tuote lasten ulottumattomissa.
- Tarkista tuote säännöllisesti vaurioiden varalta.
- Älä käytä tuotetta, jos siinä on näkyviä vaurioita tai puutteita.
- Noudata kaikkia paikallisia lakeja ja sääntöjä, jotka koskevat ampumaaseita ja niiden lisävarusteita.
- Ilmoita vaarallisista tuotteista tai onnettomuuksista paikallisille viranomaisille.

Erityiset turvallisuusohjeet käytön aikana

- Käytä aina suojaruukkeita, kuten kuulosuojaimia ja suojalaseja, ammuttaessa.
- Varmista, että ase on tyhjennetty ennen tuotteen asentamista tai säilyttämistä.
- Älä suuntaa asetta kohti mitään, mitä et ole valmis ampumaan.
- Varmista, että ampuma-alue on selkeä ja turvallinen ennen laukaisua.
- Älä käytä tuotetta, jos et ole saanut asianmukaista koulutusta sen käytöstä.

Asennus ja käyttöohjeet

1. Asennus

- Poista vanha kanta Ruger® 10/22®:sta.
- Liitä MOE® X22 kanta asentamalla se paikalleen ja varmista, että se on tiukasti kiinni.
- Tarkista, että kaikki kiinnitykset ovat kunnolla paikoillaan ennen käyttöä.

2. Käyttö

- Varmista, että ase on tyhjennetty ennen kuin käytät MOE® X22 kantaa.
- Säädä tyynyn pituus sopivaksi omalle käyttömukavuudellesi.
- Hyödynnä MLOK®-aukkoja lisävarusteiden kiinnittämiseen.
- Käytä integroituja silmukakiinnityksiä olkaimien kiinnittämiseen.

Hävittämishohjeet

- Hävitä tuote vastuullisesti paikallisten jätteen käsittelyohjeiden mukaisesti.
- Älä hävitä tuotetta kotitalousjätteen mukana.
- Tarkista paikalliset säädökset ja ohjeet, jotka koskevat ampumaaseiden ja niiden lisävarusteiden hävittämistä.

Lisätietoja ja tuki

Jos tarvitset lisätietoja tai tukea, ota yhteyttä tuotteen valmistajaan tai jälleenmyyjään. Varmista, että sinulla on tuotenumerot ja ostotiedot valmiina.

Muista, että turvallisuus on ensisijainen prioriteetti. Noudata kaikkia ohjeita ja varmista, että käytät tuotetta vastuullisesti ja turvallisesti.