

# LONG RANGER 243 WINCHESTER RIFLE MAGAZINE - HENRY REPEATING ARMS LONG RANGER 243 WINCHESTER 4 ROUND MAGAZINE BLACK

[Magazines](#) > [Rifle Magazines](#) > [Magazines](#)

Replacement/spare 4 round magazine for the Henry Long Ranger in 243 Winchester.



## Attributes

- Name: [HENRY REPEATING ARMS LONG RANGER 243 WINCHESTER 4 ROUND MAGAZINE BLACK](#)
- Manufacturer: [HENRY REPEATING ARMS](#)
- Product no.: 430109383
- Mfr. No.: H14-243-MAG
- Capacity: 4-Round
- Cartridge: 243 Winchester
- Finish: Black
- Model: Long Ranger
- Weapon type: Henry
- Delivery weight: 0.113kg
- UPC: 619835601377

## Item details

Made in USA

US export classification: 0A501.x

# Table of Contents

- Startpage
- LONG RANGER 243 WINCHESTER RIFLE MAGAZINE SAFETY INSTRUCTIONS
- About Us

# LONG RANGER 243 WINCHESTER RIFLE MAGAZINE SAFETY INSTRUCTIONS

## Introduction

Thank you for choosing the LONG RANGER 243 WINCHESTER RIFLE MAGAZINE by Henry Repeating Arms. This manual provides essential safety information and guidelines to ensure the safe use of your magazine. Please read this document carefully before using the product.

## General Safety Guidelines

- Ensure that all firearms and ammunition are stored safely and securely, out of reach of children and unauthorized users.
- Always treat every firearm as if it is loaded, even if you believe it is not.
- Use only the specified ammunition (243 Winchester) with the LONG RANGER magazine.
- Regularly inspect your magazine for any signs of damage or wear. Do not use a damaged magazine.
- Follow all local laws and regulations regarding firearm use and storage.
- In case of an accident or malfunction, seek professional assistance immediately.

## Specific Safety Precautions for Use

- Before loading the magazine, ensure that the firearm is pointed in a safe direction.
- Do not attempt to load the magazine while it is still in the firearm.
- Always keep your finger off the trigger until you are ready to shoot.
- Avoid using the magazine in adverse weather conditions (e.g., heavy rain, snow) to prevent corrosion or malfunction.
- If you experience any issues with the magazine during use, cease operation and consult a qualified gunsmith.

## Instructions for Installation and Usage

### Installation

1. Ensure that the firearm is unloaded and pointed in a safe direction.
2. Remove the existing magazine from the firearm by following the manufacturer's instructions.
3. Align the LONG RANGER 243 WINCHESTER magazine with the magazine well of the firearm.
4. Push the magazine firmly into place until you hear a click, indicating it is securely attached.

### Usage

- Load the magazine with no more than 4 rounds of 243 Winchester ammunition.
- To load, press down on the follower and insert the ammunition with the bullet facing forward.
- Ensure that the magazine is fully loaded before attempting to fire the firearm.
- After firing, remove the magazine and unload any remaining ammunition in a safe manner.

## Disposal Instructions

- When disposing of the magazine, ensure it is completely unloaded.
- Follow local regulations for disposing of firearm accessories.
- Do not throw the magazine in regular household waste. Instead, consider recycling options or contacting a local firearms dealer for disposal.

## Contact Information for Further Support

For any inquiries or concerns regarding the LONG RANGER 243 WINCHESTER RIFLE MAGAZINE, please refer to the manufacturer's website or customer service resources. Always ensure that you are following the latest safety guidelines and product recalls.

This safety instruction guide is designed to help you use your LONG RANGER 243 WINCHESTER RIFLE MAGAZINE safely and responsibly. Always prioritize safety and compliance with all relevant laws and regulations.

# About Us

## Brownells UK

### **Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories**

Unit 1, Laughing Dog Industrial Estate  
London Road  
Rugby  
Warwickshire  
CV23 9LP

[www.brownells.co.uk](http://www.brownells.co.uk)