

BRN-22 EXTRACTOR SPRING - BROWNELLS BRN-22 EXTRACTOR SPRING

[Rifle Parts](#) > [Bolt Parts](#) > [Extractor Parts](#) > [Extractor Springs](#)

Replacement BRN-22 Extractor Spring. Extractor spring is backwards compatible with standard Ruger® 10/22® bolts. Extractor is made from 0.17 inch diameter music wire.



Attributes

- Name: [BROWNELLS BRN-22 EXTRACTOR SPRING](#)
- Manufacturer: [BROWNELLS](#)
- Product no.: 430109577
- Mfr. No.: AZTP-22-00-007
- Model: BRN-22
- Weapon type: Brownells
- Delivery weight: 0.045kg
- Shipping height: 3mm
- Shipping width: 3mm
- Shipping length: 3mm
- UPC: 050806001220

Item details

Made in USA

Table of Contents

- Startpage
- BRN22 Extractor Spring Safety Instructions
- About Us

BRN22 Extractor Spring Safety Instructions

Introduction

Thank you for choosing the BRN22 Extractor Spring. This product is designed to enhance the performance of your firearm while ensuring safety during use. Please read this safety instruction guide carefully to understand how to use the extractor spring safely and effectively.

General Safety Guidelines

- Always treat firearms with respect and assume they are loaded.
- Store the extractor spring and all firearm components out of reach of children and unauthorized users.
- Inspect the extractor spring for any signs of damage or wear before installation.
- Follow all local laws and regulations regarding firearm modifications and usage.
- Be aware of your surroundings when handling firearms to avoid accidents.

Specific Safety Precautions for Use

- Ensure that the firearm is unloaded before attempting to install or replace the extractor spring.
- Use only the BRN22 Extractor Spring as a replacement for the original part to maintain firearm integrity.
- Do not modify the extractor spring; any alterations may compromise safety and functionality.
- Wear appropriate safety gear, including eye protection, when handling or working on firearms.
- If you experience any issues with the extractor spring during use, cease operation immediately and consult a professional.

Instructions for Installation and Usage

1. Preparation

- Ensure the firearm is completely unloaded.
- Gather necessary tools, including a screwdriver and any other tools specified in your firearm's manual.

2. Removing the Old Extractor Spring

- Disassemble the firearm according to the manufacturer's instructions.
- Carefully remove the old extractor spring from the bolt assembly.

3. Installing the BRN22 Extractor Spring

- Take the new BRN22 Extractor Spring out of its packaging.
- Align the new extractor spring with the bolt assembly.
- Gently press the spring into place, ensuring it is seated correctly.

4. Reassembling the Firearm

- Follow the manufacturer's instructions to reassemble the firearm.
- Ensure all parts are securely fitted and that the firearm operates smoothly.

5. Testing the Installation

- Perform a function check to ensure the extractor spring is working correctly.
- If any issues arise, consult a qualified gunsmith for assistance.

Disposal Instructions

- Dispose of the old extractor spring and any packaging materials in accordance with local waste management regulations.
- Do not dispose of the extractor spring in a manner that could harm the environment.

Contact Information for Further Support

For any safety inquiries or concerns regarding the BRN22 Extractor Spring, please consult the product packaging or visit the manufacturer's website for assistance. Always ensure you have the most up-to-date information regarding product safety and compliance.

Thank you for your attention to these safety instructions. Your commitment to safe firearm handling and maintenance is essential for your safety and the safety of others.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk