

PROGRESSIVE STAGE PRESS STEEL SHOT CHARGE BAR - MEC RELOADING 7/8OZ #1-#4 SHOT PROGRESSIVE STAGE STEEL SHOT CHARGE BAR

[Reloading](#) > [Reloading Presses](#) > [Reloading Press Accessories](#)

Steel Shot charge bar is designed for progressive reloaders. Available to load from 7/8 oz to 1-1/2 oz. of shot and BB sizes down to #6.



Attributes

- Name: [MEC RELOADING 7/8OZ #1-#4 SHOT PROGRESSIVE STAGE STEEL SHOT CHARGE BAR](#)
- Manufacturer: [MEC RELOADING](#)
- Product no.: 749019425
- Mfr. No.: 50207814
- Size: 7/8 oz
- Delivery weight: 0.234kg
- Shipping height: 25mm
- Shipping width: 25mm
- Shipping length: 165mm
- UPC: 098489017145

Item details

Made in USA

Table of Contents

- Startpage
- Safety Instruction Guide for PROGRESSIVE STAGE PRESS STEEL SHOT CHARGE BAR
- About Us

Safety Instruction Guide for PROGRESSIVE STAGE PRESS STEEL SHOT CHARGE BAR

Introduction

Thank you for choosing the PROGRESSIVE STAGE PRESS STEEL SHOT CHARGE BAR by MEC RELOADING. This product is designed for progressive reloaders and allows you to load shot from 7/8 oz to 11/2 oz, accommodating BB sizes down to #6. To ensure safe and effective use of this product, please read and follow all safety instructions outlined in this guide.

General Safety Guidelines

- Always read the entire manual before using the product.
- Keep this product out of reach of children and vulnerable individuals.
- Inspect the product for any damage before use. Do not use if damaged.
- Use only in accordance with the manufacturer's specifications.
- Report any unsafe conditions or accidents to the appropriate authorities.
- Check for recall updates on the EU's Safety Gate platform regularly.

Specific Safety Precautions for Use

- Ensure that you are using the product in a wellventilated area to avoid inhalation of any dust or particles.
- Wear safety goggles and hearing protection while operating the reloading press.
- Avoid wearing loose clothing or jewelry that may get caught in the machinery.
- Do not exceed the recommended load capacity of the charge bar.
- Handle all components, including steel shot, with care to prevent injury.
- Always follow proper reloading procedures and guidelines to prevent accidents.

Instructions for Installation and Usage

1. Preparation

- Read the product manual thoroughly.
- Gather all necessary tools and materials for installation.

2. Installation

- Ensure that the reloading press is turned off and unplugged before installation.
- Attach the steel shot charge bar to the reloading press according to the manufacturer's instructions.
- Secure all connections and ensure that the charge bar is firmly in place.

3. Usage

- Set the charge bar to the desired weight (between 7/8 oz and 11/2 oz).
- Load the shot into the charge bar as per the guidelines.
- Follow the reloading press instructions for operating the machine safely.
- Monitor the reloading process to ensure everything is functioning correctly.

4. PostUse Care

- After use, clean the charge bar and reloading press to prevent buildup of materials.
- Store the product in a dry, safe place away from children and pets.

Disposal Instructions

- Dispose of any unused or waste materials in accordance with local regulations.
- Do not dispose of the product in regular household waste. Check for designated recycling facilities or hazardous waste disposal options in your area.

Contact Information for Further Support

For any safety inquiries or further support regarding the PROGRESSIVE STAGE PRESS STEEL SHOT CHARGE BAR, please consult the manufacturer's official website or customer service.

By following these guidelines, you can ensure a safe and effective experience with your PROGRESSIVE STAGE PRESS STEEL SHOT CHARGE BAR. Thank you for your attention to safety and for choosing MEC RELOADING.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk