

PROGRESSIVE STAGE PRESS STEEL SHOT CHARGE BAR - MEC RELOADING 1-1/8OZ #4-#6 SHOT PROGRESSIVE STAGE STEEL SHOT CHARGE BAR

[Reloading](#) > [Reloading Presses](#) > [Reloading Press Accessories](#)

Steel Shot charge bar is designed for progressive reloaders. Available to load from 7/8 oz to 1-1/2 oz. of shot and BB sizes down to #6.



Attributes

- Name: [MEC RELOADING 1-1/8OZ #4-#6 SHOT PROGRESSIVE STAGE STEEL SHOT CHARGE BAR](#)
- Manufacturer: [MEC RELOADING](#)
- Product no.: 749019431
- Mfr. No.: 50211846
- Size: 1-1/8 oz
- Delivery weight: 0.231kg
- Shipping height: 25mm
- Shipping width: 25mm
- Shipping length: 165mm
- UPC: 098489016711

Item details

Made in USA

Table of Contents

- Startpage
- Safety Instruction Guide for PROGRESSIVE STAGE PRESS STEEL SHOT CHARGE BAR
- About Us

Safety Instruction Guide for PROGRESSIVE STAGE PRESS STEEL SHOT CHARGE BAR

Introduction

Thank you for choosing the PROGRESSIVE STAGE PRESS STEEL SHOT CHARGE BAR by MEC RELOADING. This safety instruction guide is designed to ensure the safe and effective use of the product. Please read all safety instructions carefully to avoid hazards and ensure a safe reloading experience.

General Safety Guidelines

- Always follow the manufacturer's instructions when using the product.
- Ensure that the product is used in a wellventilated area.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the product for any signs of wear or damage before use.
- Report any unsafe conditions or accidents to the appropriate authorities.
- Stay informed about product recalls or safety alerts via the EU Safety Gate platform.

Specific Safety Precautions for Use

- Use only the recommended shot sizes (#4 to #6) for this charge bar.
- Do not exceed the maximum load of 11/8 oz when reloading.
- Ensure that all components of the reloading press are properly assembled before use.
- Avoid wearing loose clothing or jewelry that may get caught in the machinery.
- Always wear appropriate safety gear, including eye protection and gloves, when operating the reloading press.
- Do not operate the press under the influence of alcohol, drugs, or fatigue.

Instructions for Installation and Usage

1. Installation:

- Ensure that your reloading press is securely mounted on a stable surface.
- Follow the manufacturer's instructions to attach the steel shot charge bar to your reloading press.
- Doublecheck that all connections are tight and secure before proceeding.

2. Usage:

- Set the charge bar to the desired weight (11/8 oz) according to your reloading needs.
- Load the appropriate shot size (#4 to #6) into the charge bar.
- Operate the reloading press according to the manufacturer's guidelines, ensuring smooth and consistent operation.
- Monitor the reloading process to avoid any jams or malfunctions.

Disposal Instructions

- Dispose of any unused or damaged components in accordance with local regulations.
- Do not dispose of the product in regular household waste. Check for recycling options in your area.
- Ensure that all hazardous materials are disposed of safely and responsibly.

Contact Information for Further Support

For any safety inquiries or further assistance regarding the PROGRESSIVE STAGE PRESS STEEL SHOT CHARGE BAR, please refer to the manufacturer's website or customer service. It is important to have access to reliable support for your safety and product performance.

By adhering to these safety guidelines and instructions, you will contribute to a safer reloading environment. Thank you for prioritizing safety and responsible use of the PROGRESSIVE STAGE PRESS STEEL SHOT CHARGE BAR.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk