

MEC JIG FIXTURE - MEC RELOADING MEC JIG FIXTURE

[Reloading](#) > [Reloading Presses](#) > [Reloading Press Accessories](#)

Can be mounted to bench, board, or free-standing. (Models: 600 JR., 650, 700 Versamec, Sizemaster, Steelmaster, Grabbers, 9000G, 9000H)



Attributes

- Name: [MEC RELOADING MEC JIG FIXTURE](#)
- Manufacturer: [MEC RELOADING](#)
- Product no.: 749019483
- Mfr. No.: 8958
- Delivery weight: 2.674kg
- Shipping height: 51mm
- Shipping width: 273mm
- Shipping length: 305mm
- UPC: 098489028820

Item details

Made in USA

Table of Contents

- Startpage
- MEC JIG FIXTURE Safety Instruction Guide
- About Us

MEC JIG FIXTURE Safety Instruction Guide

Introduction

Thank you for choosing the MEC JIG FIXTURE. This guide provides essential safety instructions to ensure safe use and installation of the MEC JIG FIXTURE, designed for use with various MEC reloading models. Please read this guide carefully before using the product.

General Safety Guidelines

- Always use the MEC JIG FIXTURE according to the manufacturer's instructions.
- Ensure that the workspace is clean and free of clutter before installation and use.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the MEC JIG FIXTURE for any signs of wear or damage.
- If you notice any defects or issues, cease use immediately and contact the manufacturer for assistance.
- Follow all local laws and regulations regarding reloading and the use of related equipment.

Specific Safety Precautions for Use

- Ensure that the MEC JIG FIXTURE is securely mounted to a stable surface (bench, board, or freestanding) before use.
- Do not exceed the weight limit specified by the manufacturer when attaching equipment to the jig fixture.
- Use appropriate personal protective equipment (PPE), such as safety glasses and gloves, during operation.
- Never attempt to modify or alter the MEC JIG FIXTURE in any way.
- Avoid wearing loose clothing or jewelry that could become caught in the equipment.
- Keep hands and other body parts clear of moving parts during operation.

Instructions for Installation and Usage

1. Installation:

- Choose a flat, stable surface for installation.
- If mounting to a bench or board, ensure that the surface is strong enough to support the fixture and any equipment attached.
- Use appropriate screws or bolts to secure the MEC JIG FIXTURE in place.
- For freestanding use, ensure that the base is stable and does not wobble.

2. Usage:

- Before using the MEC JIG FIXTURE, ensure that all tools and materials are within reach.
- Follow the specific instructions for your reloading model (e.g., 600 JR., 650, 700 Versamec, Sizemaster, Steelmaster, Grabbers, 9000G, 9000H).
- Always check that the fixture is properly secured and that all components are functioning correctly before starting your reloading process.
- After use, clean the MEC JIG FIXTURE to maintain its condition and ensure safe operation in the future.

Disposal Instructions

- Dispose of the MEC JIG FIXTURE in accordance with local regulations.
- If the product is damaged beyond repair, contact local waste management authorities for guidance on proper disposal methods.

- Do not dispose of the product in regular household waste if it contains hazardous materials.

Contact Information for Further Support

For any questions or concerns regarding the MEC JIG FIXTURE, please refer to the manufacturer's contact details provided with the product packaging or on the manufacturer's website.

Final Notes

Your safety is our priority. By following these guidelines, you can ensure a safe and effective experience with the MEC JIG FIXTURE. Always stay informed about safety recalls and updates through official channels. Thank you for your attention to these important safety instructions.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk