

Loading Gate Spring Cover Screw Marlin Smith & Wesson - Loading Gate Spring Cover Screw | Marlin, Smith & Wesson

[Tuotteet aseseipille](#) > [Pienet tavarat](#) > [Metalliruuvit](#)

The RPP Flyweight lever action Loading Gate greatly reduces the effort required to stoke your Rossi 95 It's a masterfully tuned, competition grade part right out of the gate. SASS approved.

Starting with a massive reduction in spring weight, the RPP gate requires only about 1.5 lbs. of force to open fully, while the factory loading gate can require in excess of 5 lbs.

Next, we redesigned the lever-action loading gate to offer substantially more clearance for cartridges, further reducing load effort. This is a significant benefit when loading fat, straight wall ammo like the Marlin 444. In fact, during testing we discovered that we could load a .444 dummy through the gate of a typical Marlin 336 .30-30, without benefit of the Model 444's magazine tube clearance bulge. That's first class leg room!

Finally, we paid very careful attention to the inside "feed lip" area of the gate, optimizing geometry to ease gate opening against an on-deck round, and offer smooth feeding, with perfect case head control. With every gate precisely CNC machined from solid bar stock and hand polished, consistent results are assured.

Material is 7075-T6 aluminum, the strongest grade available. Engineered for highly stressed air frames, 7075 has extraordinary fatigue strength for thousands of flex cycles without failure. When anodized, it has a surface hardness exceeding hardened steel, for excellent wear properties.

The Firearm Blog Review: Ranger Point Precision Cloverleaf Peep Sights + Flyweight Loading Gate Springs

RPP Flyweight Marlin Loading Gate Features:

- * Spring weight reduced by up to 70%
- * No tuning required, saving you time and hassle
- * Greatly increased cartridge clearance
- * No knife sharp edges
- * Easy loading and smooth, reliable feeding
- * Precisely machined from 7075-T6 aluminum billet and hard anodized for extreme durability
- * Available in black, gold, or clear anodized finish (silver color to closely match stainless rifles)
- * 10-15 minute installation time
- * Single Action Shooting Society (SASS) approved

NO IMAGE
AVAILABLE

INSTALLATION

A couple of good screwdrivers is all that's needed.

The gun will need to be partially disassembled - just go slow, and remember that each screw needs to return to its original home, so get a piece of cardboard box, draw an approximation of the receiver on it, and poke a hole in your drawing where each screw can rest until reassembly.

- 1) Clear the rifle & ensure the chamber and magazine are EMPTY.
- 2) Unscrew/remove the tang screw from the upper/rear receiver tang, and pull off the buttstock to the rear.
- 3) Partially open bolt/lever, remove lever pivot screw and slide lever out of the bottom of the receiver (no need to remove bolt)
- 4) De-cock the hammer with the safety disengaged. Push forward on the hammer spring bridge and pull or push out one side of its groove. This will free the hammer spring
- 5) Remove hammer pivot screw, bottom trigger plate screw and side support screws to free the trigger plate from the receiver.
- 6) Remove the trigger plate / lower tang from the bottom of the receiver (some gentle prying may be needed).
- 7) Pull the locking lug out of the bottom of the receiver and swing the carrier out of the receiver (no need to remove the carrier pivot screw)
- 8) Unscrew the loading gate spring (1" behind the loading gate opening) and install the new gate and screw it in

Reassemble in reverse order.

Ominaisuudet

- Nimi: [Loading Gate Spring Cover Screw | Marlin, Smith & Wesson](#)
- Valmistaja: [RANGER POINT](#)
- Tuotenro: EU2014804
- Valm.nro: 200
- Toimituksen paino: 0.45kg
- Toimituksen korkeus: 2.54mm
- Toimituksen leveys: 6.35mm
- Toimituksen pituus: 6.35mm
- UPC: 850078134127

Sisällysluettelo

- [Etusivu](#)
- [Käyttöohjeet ja turvallisuusohjeet: Loading Gate Spring Cover Screw](#)
- [Tietoa meistä](#)

Käyttöohjeet ja turvallisuusohjeet: Loading Gate Spring Cover Screw

Johdanto

Tervetuloa RANGER POINT tuoteperheen pariin! Tämä käyttöohje kattaa Loading Gate Spring Cover Screwin turvallisen käytön, asennuksen ja hävittämisen. Tuote on suunniteltu parantamaan Rossi 95 aseennun latausprosessia, ja se on SASShyväksytty. Lue tämä ohje huolellisesti ennen tuotteen käyttöä tai asennusta varmistaaksesi turvallisen ja tehokkaan käytön.

Yleiset turvallisuusohjeet

- Varmista, että tuote on asennettu oikein ennen käyttöä.
- Tarkista tuote säännöllisesti vaurioiden tai kulumisen varalta.
- Älä käytä tuotetta, jos siinä on näkyviä vaurioita tai puutteita.
- Säilytä tuote lasten ulottumattomissa.
- Ilmoita viranomaisille kaikista vaarallisista tuotteista tai onnettomuuksista.

Erityiset turvallisuustoimenpiteet käytössä

- Varmista, että ase on tyhjennetty ja että patruunat on poistettu ennen tuotteen asennusta tai huoltoa.
- Älä koskaan suuntaa asetta kohti ihmisiä tai eläimiä, vaikka se olisi tyhjennetty.
- Käytä aina suojaruukkeita, kuten suojalaseja, kun käsittelet asetta.
- Vältä liiallista voimaa asennusprosessissa, jotta vältät vaurioita tuotteelle tai aseelle.
- Varmista, että käytät vain suositeltuja työkaluja asennuksessa.

Asennus ja käyttöohjeet

Asennus vaatii vain muutaman ruuvimeisselin. Ase on osittain purettava. Käytä seuraavia ohjeita asennuksen suorittamiseen:

1. **Tyhjennä ase** ja varmista, että patruunat ja lipas ovat tyhjät.
2. **Poista takaruuvit** ylemmästä/takaisesta vastaanottotangosta ja vedä peräosa taaksepäin.
3. **Avaa osittain lukko/painike**, poista vivun pivotruuvi ja vedä vivu pois vastaanottimen pohjalta (ei tarvitse poistaa lukkoa).
4. **Poista vasara** purkamalla vasaran jousisilta. Työnnä eteenpäin vasaran jousisillasta ja vedä tai työnnä yksi puoli pois urastaan. Tämä vapauttaa vasarajousen.
5. **Poista vasaran pivotruuvi**, alakäynnistyslevyn ruuvi ja sivutukiruuvit vapauttaaksesi käynnistyslevyn vastaanottimesta.
6. **Poista käynnistyslevy / alatanko** vastaanottimen pohjasta (voi tarvita varovaisia nostotoimia).
7. **Vedä lukitusluku** alas vastaanottimen pohjasta ja käännä kuljettaja pois vastaanottimesta (ei tarvitse poistaa kuljettajan pivotruuvia).
8. **Poista latausportin jousi** (1 tuuman päässä latausportin aukosta) ja asenna uusi portti ja ruuvi.

Kokoa ase takaisin käänteisesti.

Hävittämisohteet

- Tuote on hävitettävä paikallisten jätteen käsittelyohjeiden mukaan.
- Älä hävitä tuotetta kotitalousjätteen mukana.
- Ota yhteys paikallisiin viranomaisiin tai jätehuoltopalveluihin, jos et ole varma oikeasta hävittämistavasta.

Lisätietoja ja tuki

Jos tarvitset lisätietoja tai tukea, ota yhteyttä valmistajaan tai paikalliseen jälleenmyyjään. Muista tarkistaa EU:n Safety Gate alustalta mahdolliset tuotevetoomukset tai turvallisuustiedotteet.

Loppusanat

Kiitos, että valitsit RANGER POINT tuotteet. Oikein käytettynä tämä tuote parantaa latauskokemustasi ja tekee siitä turvallisen ja tehokkaan. Noudata aina näitä ohjeita varmistaaksesi turvallisen käytön.

Tietoa meistä

Brownells Finland

Brownells Finland - Laajin valikoima erilaisten aseiden osia

Kutojantie 3 (ei myymälää)

02630 Espoo

www.brownells.fi