

1911 9MM LUGER FLAT WIRE RECOIL SPRING - ED BROWN 1911 COMMANDER 9MM LUGER 15# FLAT WIRE RECOIL SPRING

[Handgun Parts](#) > [Recoil Parts](#) > [Recoil Springs](#)

The flat wire spring for 1911 handguns is a must for any handgun enthusiast or full time shooter. Manufactured from Chrome Silicon alloy to maximize spring longevity and load. The longest lasting handgun recoil spring made - up to ten times greater service life than a conventional coil spring. Other benefits of switching from conventional round wire to flatwire include improved cycling and more tolerant to a wider variety of loads. Intended for use with our flat wire guide rod system. Recommended spring replacement at 30,000-40,000 rounds. Will not work with a standard recoil spring guide and plug, only the flat wire guide rod and plug.



Attributes

- Name: [ED BROWN 1911 COMMANDER 9MM LUGER 15# FLAT WIRE RECOIL SPRING](#)
- Manufacturer: [ED BROWN](#)
- Product no.: 430109541
- Mfr. No.: 915-FW-9C
- Model: Commander
- Pounds: 15 lbs
- Weapon type: 1911
- Delivery weight: 0.227kg
- Shipping height: 13mm
- Shipping width: 102mm
- Shipping length: 229mm
- UPC: 800732915005

Item details

Made in USA

Table of Contents

- Startpage
- Safety Instruction Guide for 1911 9MM LUGER FLAT WIRE RECOIL SPRING
- About Us

Safety Instruction Guide for 1911 9MM LUGER FLAT WIRE RECOIL SPRING

Introduction

Thank you for choosing the 1911 9MM LUGER FLAT WIRE RECOIL SPRING by ED BROWN. This product is designed to enhance the performance of your 1911 Commander handgun. Please read this safety instruction guide carefully to ensure safe and effective use of the recoil spring.

General Safety Guidelines

- Always ensure your firearm is unloaded before installing or handling the recoil spring.
- Use the recoil spring only with the specified flat wire guide rod system.
- Regularly inspect the recoil spring for wear and tear, and replace it after 30,00040,000 rounds as recommended.
- Store the recoil spring in a cool, dry place away from direct sunlight and moisture.
- Keep this product out of reach of children and unauthorized users.
- Report any unsafe products or accidents to the appropriate authorities.

Specific Safety Precautions for Use

- **Potential Hazards:**
 - Improper installation may lead to malfunction or failure of the firearm.
 - Using the recoil spring with a standard recoil spring guide and plug may cause damage.
- **Avoiding Hazards:**
 - Follow installation instructions carefully to ensure proper fit and function.
 - Do not exceed the recommended round count for spring replacement.
 - Be mindful of the spring's tension during installation and removal to prevent injury.

Instructions for Installation and Usage

1. Preparation:

- Ensure the firearm is completely unloaded.
- Gather necessary tools for installation (if applicable).

2. Installation Steps:

- Remove the existing recoil spring and guide rod from the firearm.
- Insert the flat wire recoil spring into the flat wire guide rod system.
- Ensure the spring is seated properly and securely.
- Reassemble the firearm according to the manufacturer's instructions.

3. Usage:

- Regularly check the recoil spring for signs of wear, such as deformation or loss of tension.
- Replace the recoil spring after firing between 30,00040,000 rounds.
- Do not use the recoil spring with any other guide rod system or plug.

Disposal Instructions

- Dispose of the recoil spring in accordance with local regulations.
- Consider recycling options for metal components where applicable.

Contact Information for Further Support

For any questions or concerns regarding the use of the 1911 9MM LUGER FLAT WIRE RECOIL SPRING, please consult the manufacturer's website or customer service.

Thank you for prioritizing safety and performance with your firearm. Enjoy your shooting experience responsibly!

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk